Quick Setup Guide

DX-PHD25 2.5" PATA Hard Drive Disk Enclosure

Package contents

- USB 2.0 2.5" PATA hard drive enclosure
- USB 2.0 Y cable A to Mini B
- Utility CD with *User Guide* and *Roxio BackOnTrack* software
- Screwdriver
- *Quick Setup Guide*

System requirements

- Computer with an available USB 2.0 port
- 2.5" PATA hard drive
- Windows 7, Windows Vista, and Windows XP operating system
- MAC OS X version 10.4 or higher operating system

For highest performance and reliability, install the latest updates and service pack (SP). For Windows, go to the **Start** menu, then select **Windows Update**.

Features

Installing your hard drive in the enclosure

1 Remove two screws on the left side of panel.



2 Pull out the plastic end cap with the circuit board.



3 Connect the drive's data connector to the corresponding connector on the enclosure circuit board.



4 Place the hard drive with the plastic cap back into the aluminum housing, then secure it with the two screws you previously removed.



Connecting the enclosure to your computer

Note: Make sure you have already installed a hard drive into the enclosure before you connect the enclosure to your computer.


USB 2.0 A male-type connector for additional power
USB 2.0 A male-type connector for data and bus power
USB 2.0 Mini B connector

1 Plug the Mini B type connector into the USB port on enclosure, then plug the other end of the cable into a USB port on your computer. For additional power, connect the extra USB connector to the computer, especially for large capacity hard drives.

Note: A good rule of thumb would be to use one connector initially, then if your computer does not recognize the drive, plug in the second connector.

2 The operating system automatically detects and sets up the new drive. The enclosure/hard drive turns on and the LED blinks. If the drive is correctly detected, a new drive letter is assigned.

- For PCs, the new drive letter appears in *My Computer*.
- For Macintosh computers, the new drive letter appears on your desktop.



3 If the drive is new and is not formatted, follow the steps below to format the drive. Otherwise, continue to "Installing the backup software".

Formatting the hard drive

For Windows users:

1 Right click **My Computer** (or **Computer** depending on what version of Windows you have), then click **Manage**.
2 Under *Storage* on the LEFT pane, select **Disk Management**.
3 Click on the new drive, then click on the *Action* tab at the top of screen.
4 Go to *All Tasks*, then click **Format** from the menu.
5 Select other choices you want, then click **OK**.

For Macintosh users:

1 Start the *Disk Utility* tool (under *Applications*).
2 Select the new hard drive you are trying to install.
3 Click the **Erase** tab.
4 Choose a volume format and assign a name to the new drive.
5 Click **Erase**.
6 Once complete, an icon for your new hard drive appears on your desktop.

Installing the software

This Utility CD includes backup software to enable you to back up your files.
Note: This *Roxio BackOnTrack* software only runs on Windows 7, Windows Vista, or Windows XP computers.
Important: Before installing the backup software, make sure that your Windows operating system has been updated to the latest service pack.

To install backup software:

1 Save all files and close all programs.
2 Insert the included utility CD into your optical drive. Your computer automatically detects the CD. Or, if the screen does not open, locate the CD in Windows Explorer and double-click **Run.exe** on the CD. The initial menu opens.
3 Click **Install Backup Software**. The *Welcome* screen opens.
4 Click **Next**. Then *Roxio End-User License Agreement* screen opens.
5 Read the license agreement, click "I accept...," then click **Next**. The *Choose Setup Type* screen opens.
6 Choose the setup type, then click **Install** to start installation. It may take several minutes to install the software.
7 When installation is complete, the *Setup Wizard Completed* screen opens.
8 Click **Finish** to complete the installation.

See your *User Guide* located on the CD for information on using the software.

Using one-touch backup

To use one-touch backup if you have set up a backup project:

Press the *One-Touch* button on the side of the HDD enclosure. The backup process begins.

To use one-touch backup if you have NOT set up a backup project:

1 Press the **One-Touch** button on the side of the HDD enclosure. The *Roxio BackOnTrack* software opens with the *Backup files* pages displayed.
2 Follow the on-screen instructions to set up a backup project.
3 After a backup project is set up, push the **One-Touch** button to backup your data.
4 To modify *One-Touch* backups in the future, follow the instructions for setting up backup projects in your *User Guide*.

Disconnecting the enclosure from your computer

For Windows users:

Note: If a drive window is open or the hard drive enclosure is active, close any associated windows before attempting to remove the enclosure.

1 Right-click the **Safely Remove Hardware** icon (located near the clock on the taskbar).
2 Select the drive you want to unplug, then click **STOP**.
3 When Windows notifies you that it is safe to do so, unplug the enclosure from your computer.

For Macintosh users:

1 Drag the **USB** icon into the **TRASH**.
2 Unplug the enclosure.

One-year limited warranty

For complete warranty, visit www.dynexproducts.com.

Contact Dynex:

For customer service call 1-800-305-2204
www.dynexproducts.com

© 2011 BBY Solutions, Inc. All Rights Reserved.
DYNEX is a trademark of BBY Solutions, Inc. Registered in some countries. All other products and brand names are trademarks of their respective owners.